



ROVER 400 (RT) (ALL MODELS)

MAINTENANCE CHECK SHEET

Mr./Mrs/Ms: _____ Model: _____ Reg.No: _____
 Invoice/Job no: _____ Odometer reading: _____ V.I.N: _____

Service type:	FS	A	B	A	B	A	B	A	B		
Months/0,000 miles:	3	12	24	36	48	60	72	84	96	108	120

Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked *

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost.

PRELIMINARY

1. Before commencing work, check for any outstanding service actions.

FIRST SERVICE

2. Replace engine oil and filter - **First 3000 miles only. 416 Automatic only**

MAIN SERVICE

3. Annual corrosion/cosmetic inspection - **Using annual corrosion inspection sheet**

4. Replace engine oil and filter

5. Replace automatic gearbox oil

6. Replace antifreeze - **36k and then every 24k**

7. Check battery connections and antifreeze

8. Check brake, PAS, clutch & gearbox fluid levels

9. Check pressure sensing hoses and vacuum pipes

10. Replace camshaft drive belt- **NOT 420 Diesel**

11. Replace camshaft and injection pump drive belt- **420 Diesel**

12. Adjust valve clearances - **416 Automatic**

13. Check cooling system hoses and connections for signs of leakage and condition

14. Check fuel & clutch pipes and hoses for signs of leakage and condition

15. Check condition of crankcase vent hoses & valves where fitted

16. Check air conditioning system, hoses and sight glass

17. Replace auxiliary drive belt - **420 petrol**

18. Check auxiliary drive belts tension and condition

19. Replace air cleaner element - **NOT 420 Diesel**

20. Replace air cleaner element - **420 Diesel**

21. Replace fuel filter - **NOT 420 Diesel or 420 Petrol**

22. Replace fuel filter - **420 Diesel**

23. Replace fuel filter - **420 Petrol**

24. Check P.C.V. valve - **416 automatic only**

25. Replace spark plugs

26. Replace brake fluid - **Every 24 months regardless of mileage*(indicate replacement on service record)**

27. Check exhaust system and heat shields

28. Remove front road wheels

29. Check front brake linings, disc, calipers, hoses and pipes

30. Remove rear road wheels

31. Check rear brake linings, drums, disc, cylinders, calipers, hoses and pipes

32. Check road wheels

33. Check suspension and steering for signs of leaking or wear

34. Check wheel bearings, drive shafts and gaiters

35. Adjust handbrake - **First 12,000 miles only**

MAIN SERVICE

36. Replace air intake (pollen) filter (if fitted)

37. Check handbrake operation

38. Lubricate strikers, latches (use Rover lock grease) door hinges and door checks

39. Check front screen number plates and V.I.N- **36 months and then every 12 months**

40. Check seatbelt and airbag module covers - **36 months and then every 12 months**

41. Check tyre pressures, condition and tread depth (mm)

LHF RHF RHR LHR Spare

42. Check lamps, horns, and system warning indicators

43. Check screen wipers and washers

44. Replace alarm handset batteries

10 YEAR REPLACEMENT - AIRBAGS

45. Replace airbag module(s)*

46. Replace airbag rotary coupler* - **When driver only airbag fitted**

AFTER EACH MAIN SERVICE

47. Check oxygen sensor operation - **at 36 months and then every 12 months**

48. Check CO at tailpipe- **at 36 months and then every 12 months. (Record CO%)**

49. Check Smoke emissions - **220 Diesel at 36 months and then every 12 months**

50. Carry out road test, check for the correct function of all vehicle systems

The maintenance items listed, are those recommended for vehicles operating under normal driving, road and climatic conditions. More frequent attention may be necessary if the vehicle is subject to stop/start operation, extremes of temperature, dusty conditions or frequent towing of trailers.

Service check completed, cosmetic/corrosion inspection check completed and service portfolio book stamped

Name: _____ Signature: _____ Date: _____

GLOSSARY

FIRST SERVICE = The first service required after sale of vehicle. This service is only applicable to certain models as indicated by the maintenance check sheet.

MAIN SERVICE = The main service is applicable to all vehicles. It is carried out at 12 month or 12,000 miles intervals, whichever occurs first.

Main Service "A" is applicable at 12 months/12,000 miles, 36 months/36,000 miles, 60 months/60,000 miles 84 months/84,000 miles and so on.

Main Service "B" is applicable at 24 months/24,000 miles, 48 months/48,000 miles, 72 months/72,000 miles, 96 months/96,000 miles and so on. Some items do not need to be carried out at every main service and these items are identified by an indicator in the tick box e.g. 60k (This indicates that this item is only applicable every 60 months/ 60,000 miles)

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.