

Mr/Mrs/Ms _____ Model _____ Reg No _____

Invoice/Job No _____ Odometer reading _____ VIN _____



Rover 45 / MG ZS

MAINTENANCE CHECK SHEET (Petrol Models)

Service type	A	B	A	C	A	B	A	C
Years / Miles x 1000	1 / 15	2 / 30	3 / 45	4 / 60	5 / 75	6 / 90	7 / 105	8 / 120

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.

A B C Preliminary

1 Before commencing work, check for any outstanding service actions

VEHICLE INTERIOR AND EXTERIOR

- 2 Fit vehicle protection kit
- 3 Replace alarm handset batteries
- 4 Check handbrake operation and adjust if necessary.
- 5 Check lamps, horns and system warning indicators
- 6 Check screen for damage and operation of wipers and washers - Adjust washers if required
- 7 Check seatbelt operation, seatbelts and airbag module covers for damage.
- 8 Check air conditioning system operation - If applicable
- 9 Replace air intake pollen filter (if fitted)
- 10 Lubricate locks, strikers, latches, door hinges and door checks
- 11 Lubricate sunroof seal

ENGINE BAY

- 12 Check battery connections and battery condition indicator colour and charge condition.
- 13 Check and top up brake, clutch, power steering and screen washer fluid levels
- 14 Check brake servo vacuum pipe condition
- 15 Pressure test cooling system and coolant cap, check hoses and connections for signs of leakage and condition - Use tool No 26R001
- 16 Check and record anti freeze content Concentration % or degrees C - (Concentration must be corrected if below 50%) - Use tool No 26R003
- 17 Inspect air conditioning system hoses and sight glass
- 18 Check auxiliary drive belts, tension and condition
- 19 Replace air cleaner element - **Every 45,000 miles or every 3 years, whichever is the sooner**
- 20 Replace fuel filter - **Every 60,000 miles or every 4 years, whichever is the sooner**
- 21 Replace spark plugs - **Every 60,000 miles or every 4 years, whichever is the sooner**
- 22 **LPG items only refer to vehicles fitted with MG Rover approved LPG system**
- 23 Replace spark plugs - **Every 15,000 miles or every year, whichever is the sooner - Models fitted with LPG**
- 24 Replace pressure regulator filter - **Every 60,000 miles or every 4 years, whichever is the sooner - Models fitted with LPG**
- 25 Check LPG operating pressure and adjust if required - **Every 30,000 miles or 2 years, whichever is the sooner - Models fitted with LPG**
- 26 Connect T4 carry out Engine Management fault code read and clear codes. Reset Fuelling Adaptions. Check operation of coolant fan/s

Check for new tune availability and download new tunes if required - **Charged Separately**

