



ROVER 45
(Petrol models)

MAINTENANCE CHECK SHEET

Mr/Mrs/Ms _____ Reg No _____

Model _____

VIN _____

Odometer reading _____

See back page for maintenance plan

| | | | |
|------------|------------|------------|------------|
| Inspection | Inspection | Inspection | Inspection |
| A | B | C | D |

Service type _____
Service required _____

Adjust/Lubricate/Replace - Labour cost including in scheduled time except items marked*

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost

PRELIMINARY

- 1 Before commencing work, check for any outstanding service actions
- A B C D VEHICLE INTERIOR**
- 2 Check handbrake operation
- 3 Adjust handbrake - **First 15,000 miles only/first year**
- 4 Check lamps, horns, and system warning indicators
- 5 Check screen wipers and washers
- 6 Replace alarm handset batteries
- 7 Lubricate strikers, latches (use Rover lock grease) door hinges and door checks
- 8 Check seatbelt and airbag module covers - **36 months and then every year**

VEHICLE EXTERIOR

- 9 Lubricate sunroof seal
- 10 Remove front road wheels
- 11 Check front brake linings, disc, callipers, hoses and pipes
- 12 Check wheel bearings, drive shafts and gaiters
- 13 Check suspension and steering for signs of leaking or wear
- 14 Remove rear road wheels
- 15 Check rear wheels
- 16 Check rear brake linings, drums, disc, cylinders, calliper's, hoses and pipes
- 17 Check tyre pressures and adjust if necessary, including spare (bat)
 LHF RHF RHR LHR Spare
- 18 Check tyre for damage and tread depth, including spare (mm)
 LHF RHF RHR LHR Spare
- 19 Check front screen number plates and V.I.N. - **36 months and then every year**
- 20 Check exhaust system and heat shields
- 21 Annual corrosion/cosmetic inspection - **Using annual corrosion inspection sheet**

UNDER BONNET

- 22 Replace engine oil and filter
- 23 Replace manual gearbox oil - **Every 105,000 miles/7 years**
- 24 Replace automatic gearbox oil - **1.8**
- 25 Replace automatic gearbox oil - **Every 60,000 miles KV6/4 years**
- 26 Replace antifreeze* - **Every 2 years AFC, every 4 years XLC (OAT)**
- 27 Replace fuel filter - **Every 60,000 miles/4 years**
- 28 Check battery connections and antifreeze
- 29 Check brake, PAS & gearbox fluid levels
- 30 Check pressure sensing hoses and vacuum pipes

A B C D UNDER BONNET

- 30 Replace camshaft drive belt(s)
- 31 Check cooling system hoses and connections for signs of leakage and condition
- 32 Check fuel & clutch pipes and hoses for signs of leakage and condition
- 33 Check condition of crankcase vent hoses & valves where fitted
- 35 Check air conditioning system, hoses and sight glass
- 36 Check auxiliary drive belts tension and condition
- 37 Replace auxiliary drive belts - **Every 120,000 miles/8 years**
- 38 Replace air cleaner element - **Every 45,000 miles/3 years**
- 39 Replace spark plugs - **Every 60,000 miles/4 years**
- 40 Replace air intake pollen filter (if fitted)
- 41 Replace brake fluid - **Every 24 months regardless of mileage* Indicate replacement on service record)**
- 15 YEAR REPLACEMENT**
- 42 Replace airbag module(s)
- 43 Replace seatbelt pre-tensioners regardless of mileage*
- 44 Replace airbag rotary coupler*
- AFTER EACH SERVICE**
- 45 Carry out road test, check for the correct function of all vehicle systems

The maintenance items listed are those recommended for vehicles operating under normal driving, road and climatic conditions. More frequent attention may be necessary if the vehicle is subject to stop/start operation, extremes of temperature, dusty conditions or frequent towing of trailers.

Service check completed, cosmetic/corrosion inspection check completed and service portfolio book stamped.

Name _____ Signature _____ Date _____

MAINTENANCE PLAN

The following table indicates the time and distance intervals at which the relevant services are required. However in some cases, where lower than average distance is covered, the service should be carried out at the yearly intervals stated below.

The services must be carried out at the distance or time intervals listed below **(Which ever occurs first)**

| Approximate Distance/Years | Inspection (A) | Inspection (B) | Inspection (C) | Inspection (D) |
|----------------------------|----------------|----------------|----------------|----------------|
| 15,000 miles/1 Year | X | | | |
| 30,000 miles/2 Years | | X | | |
| 45,000 miles/3 Years | X | | | |
| 60,000 miles/4 Years | | | X | |
| 75,000 miles/5 Years | X | | | |
| 90,000 miles/6 Years | | | | X |
| 105,000 miles/7 Years | X | | | |
| 120,000 miles/8 Years | | X | | |
| 135,000 miles/9 Years | X | | | |
| 150,000 miles/10 Years | | | | X |

ARDUOUS DRIVING CONDITIONS - ADDITIONAL REQUIREMENTS

| Driving Condition | Maintenance Item | Task | Interval |
|-------------------------------------|------------------------------------|----------|---------------------------------|
| V W X Z | Engine oil and filter | R | Every 7,500 miles or 6 months |
| W Y | Air cleaner element - all models | R | Every 15,000 miles or 12 months |
| W X Y | Ancillary drive belt - all models | I | Every 15,000 miles or 12 months |
| W Y Z | Front and rear brakes - all models | I | Every 15,000 miles or 12 months |
| W Y | Suspension and steering components | I | Every 15,000 miles or 12 months |

Driving Condition Code

- V** = Repeated short distance driving (e.g. up to 5 miles), or stop start; driving or idling for long periods
- W** = Driving in dusty and/or sandy conditions
- X** = Driving in extremely hot conditions
- Y** = Driving on rough and/or muddy roads
- Z** = Towing a trailer or driving in mountainous conditions

Task Codes

- I** = Inspection
- R** = Replace
- S** = Service