

Mr/Mrs/Ms

Model

Reg No

Invoice/Job No

Odometer reading

VIN

A	A	B	A	A	C	A	A	B	A	C
5	10	15	20	25	30	35	40	45	50	60
		1			2			3		4
Oil	Oil	Inspection	Oil	Oil	Inspection	Oil	Oil	Inspection	Oil	Inspection

Oil Service Intervals are based on 5,000 miles irrespective of time. An Inspection must be carried out at least once every year as identified above

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.

# ROVER / MG ZT - ZTT MAINTENANCE CHECK SHEET (260PS V8 models)

## Preliminary

1  A  B  C Before commencing work, check for any outstanding service actions

## VEHICLE INTERIOR AND EXTERIOR

- 2  Fit vehicle protection kit
- 3  Replace alarm handset batteries
- 4  Check handbrake operation and adjust if necessary.
- 5  Check lamps, horns and system warning indicators
- 6  Check screen for damage and operation of wipers and washers - Adjust washers if required
- 7  Check seatbelt operation, seatbelts and airbag module covers for damage.
- 8  Check air conditioning system operation - If applicable
- 9  Replace air intake pollen filter - **Every 30,000 miles or 2 years whichever is the sooner**
- 10  Lubricate locks, strikers, latches door hinges and door checks

## ENGINE BAY

- 11  Check and top up brake, clutch, power steering and screen washer fluid levels
- 12  Pressure test cooling system and coolant cap, check hoses and connections for signs of leakage and condition - Use tool No 26R001
- 13  Check and record anti freeze content  **Concentration % or degrees C - ( Concentration must be corrected if below 50% ) - Use tool No 26R003**
- 14  Inspect air conditioning system hoses
- 15  Check auxiliary drive belts, tension and condition
- 16  Replace spark plugs - **Every 90,000 miles or every 6 years, whichever is the sooner**
- 17  Replace PCV valve - **Every 90,000 miles or every 6 years, whichever is the sooner**
- 18  Check condition of engine mountings, paying particular attention to hydraulic mountings - **Every 30,000 miles or 2 years whichever is the sooner**
- 19  Check torque of accessible engine mounting fixings - **Every 60,000 miles or every 4 years, whichever is the sooner**
- 20  Connect T4 carry out fault code read
- 21  Reset Service Interval Indicator in accordance with manufacturers guidelines

